

shelter

gammamax
the family tent



shelter and protection solutions

shelter

The Gammax design has been deployed in various rough areas during the past decade, serving mainly as accommodation. The winterized version has been selected by international NGO's and UN agencies to be utilized in the Caucasus, the Balkans, the Middle East and in Afghanistan, among other areas. The shape and composition secures stability and efficient heating of the temporary shelter. Reports from several operations substantiate the value-for-money concept; the Gammax has been in use for more than three years in some camps.

The Gammax comes in three versions, the basic tent and the Foyer for cold climates, and the Gammax II for tropic climates. The latter is not equipped with inner lining, but has very large, fly-screened windows. The Foyer is the direct result of an important and relevant input from one NGO after an operation. They wanted to improve the quality of life for the residents by adding an entrance section. To respond accordingly as a designer and manufacturer of tent solutions is the way we work.

Gammax is one of the items that ROFI Industrier keep in stock through our commitment in NOREPS, Norwegian Emergency Preparedness System. 24 hours a day, 365 days a year, we are able to deliver the NOREPS commodities to an international airport within 24 hours, and upon several occasions we have accordingly performed. Our technicians are available for organising and supervising partial or complete turnkey projects in the field. This professional assistance is also available 24 hours a day, year around.



ROFI Industrier as represents more than 60 years of experience within the textile industry. A comprehensive integration with our suppliers and partners enable us to meet the requirements for progressive development, system solutions and a stock-hold of selected items. We continuously maintain our certificate covering quality assurance/quality control.



ROFI Industrier as

Normeca AS
 SUPPLIER OF MOBILE HOSPITALS
 Mailandvn 12, P.O. Box 404, 1470 Lorenskog - Norway
 Tlf.: +47 67 92 76 00 - Fax: +47 67 92 76 92
 Mail: post@normeca.no - Web: www.normeca.no

www.rofi.com



gammax the family tent for various climates



The Gammax Family Tent comes in several versions; one of them with outer- and inner fly and a very durable ground sheet out of coated polyester. Be aware of the 30 cm high splash wall made from the very same rot-proof material, avoiding rottness or moisture to the main canvas from cotton. Cotton is preferred as the main canvas due to its ability to «breath the air» - and preventing condense to occur. In tropic areas, large windows covered with mosquito netting ensure sufficient ventilation. The roof is prepared for a stove chimney apron to be installed, whenever that is required.

BASIC SPECIFICATIONS

	GAMMAX	GAMMAX II	FOYER
Base area	24 m ²	24 m ²	27 m ²
Center height	240 cm	240 cm	240 cm
Wall height	125 cm	125 cm	160/125 cm
Poles	aluminium	aluminium	aluminium
Splash wall	30 cm high	30 cm high	30 cm high
Ground sheet, coated	PES, 450 g/m ²	PES, 450 g/m ²	PES, 450 g/m ²
Ground strip, coated	PES, 450 g/m ²	PES, 450 g/m ²	integrated
Inner fly	cotton, 200 g/m ²	NA	cotton, 200 g/m ²
Weight	54 kg	42 kg	56 kg
Volume	0.16 m ³	0.15 m ³	0.21 m ³

Specifications may be altered without notice due to progressive product development.

shelter and protection solutions